



Jumper**
 These three jumpers are used for with the Tuna Topper Amp. Connect from the marked pads on the rectangle area of the PCB to the pads adjacent to the jacks on the edge of the PCB

See assembly drawing for use of Jp4 for fast/slow T/R switch